BRIEF INSTRUCTION MANUAL FOR OMEGA SAFE

Factory setting state:

.The initial user password is 1234

.Any empty fingerprint cannot open the door

1-Set user password

1-1 Press the settings button

1-2 Enter a 1 to 8 digit password (enter any password after 8 digits to overwrite the 8th digit), press "#"

1-3 Enter the password again and press "#" . If the two entered passwords are the same,you will hear a long "beep" , indicating the new password is set successfully. If the entered two passwords are not the same, you will hear a "beep beep beep" .

2-Add fingerprints (Register by pressing four times, up to 20 fingerprints can be registered)

2-1 Press the settings button

2-2 Place the finger to be registered centrally on the fingerprint scanner, you will hear a short sound "beep", remove the finger and press again, repeat 4 times, you will hear a long "beep", indicating successful fingerprint registration.

3-Restore factory setting

Hold the setting button for 2 to 3 seconds,you will hear a long "beep" , the user password is initialized to "1234" and the fingerprint is cleared

4-Open door with a password or fingerprint

4-1 Open with password: press the # key, then enter the correct password, press # again to verify and open the door.

4-2 Open with fingerprint : press your finger on the fingerprint scanner, the door can be opened after successful identification.

When incorrect password or fingerprint is entered, the error light will turn on and the buzzer will beep

5-Mute function:

Hold "*" for about 3 seconds, the correct light will be on, mute function activated.

Hold "*" for another 3 seconds, the correct light will be on, sound restored.

Note: "*" is the the mute function toggle key, the normal sound will be restored after power off.

6-Low voltage

When the power supply voltage is insufficient, while the system exits after use, you will hear 5 short "beep", indicating it's time to replace the battery. You can also use the outer battery supply to open the safe when the battery power is run out.

Emergency: For your convenience we have engineered a manual override system into your safe. If necessary, slide the small cover on the right of the panel, and insert the key and turn it anticlockwise, then rotate the panel in the clockwise direction. This will permit you to open manually your safe at any time.

Important: never keep the emergency keys inside the safe !